




## Mounting instruction – Gutter Brackets

*(For rafter and fascia gutter brackets with diameter of 105mm (250), 127mm (280), 153mm (333), 192mm (400) that are galvanized or powder coated designed for metal rainwater systems)*

ZPHU "Hak-Mar" guarantees its products to maintain top quality and its functional and aesthetic properties as long as the following mounting instructions are followed:

- Brackets bender needs to be used for bending rafter brackets in order not to mechanically damage galvanized or paint coating, brackets should be only fixed to the rafter with screws
- Bracket has to be bent and installed in positive temperatures
- Brackets (both rafter and fascia) should not be fixed with gaps bigger than 80cm between them *(the maximum gap is 100cm)*
- Brackets are designed to be used in normal environmental conditions *(products are not designed to be used on sites located in the areas of aggressive environmental conditions e.g. air with high levels of pollution or salt etc.)*
- Products can not stay in prolonged contact with rusty objects, strong chemicals, or objects made of lead

On behalf of the manufacturer signed by:



Andrzej Nocoń - Company owner